

MeshCore Repeater

Diagnostics via Serial Console

The MeshCore serial console provides direct access to repeater state and diagnostic information. Connecting via USB to a deployed repeater is the most reliable way to diagnose problems that cannot be addressed remotely.

Connecting to the Serial Console

On Windows: use PuTTY or the Arduino Serial Monitor. On Linux/Mac: use `screen` or `minicom` as a serial terminal.

```
# Linux/Mac
screen /dev/ttyUSB0 115200

# Windows (PuTTY): Connection Type = Serial, Speed = 115200, COM port varies
```

MeshCore boards use 115200 baud for the serial console, including RAK boards. (If you have configured an attached GPS module, that module's own UART may run at a different baud rate such as 9600 - but that is a separate interface from the console.)

Key Diagnostic Commands

These are commands from the on-device MeshCore serial CLI (see docs.meshcore.io/cli_commands). There is no single combined "status" command - health information is split across several `get ...` and `stats-...` commands.

Command	Output	Use for
<code>ver</code>	Firmware version	Confirm firmware build
<code>stats-core</code>	Battery voltage, uptime, queue depth	Overall health check

Command	Output	Use for
<code>get radio</code> / <code>get freq</code>	Radio config (frequency, bandwidth, SF, coding rate)	Verify radio settings match the network
<code>neighbors</code>	Up to the 8 most recently heard nodes, with timestamp and SNR	Verify which nodes are reaching this repeater
<code>stats-packets</code>	Packet counters: Received and Sent	Identify traffic/routing problems
<code>stats-radio</code>	Noise floor, last RSSI/SNR, airtime, receive errors	Signal quality of last received packet
<code>log</code>	Prints a captured rx log (must first be started with <code>log start</code> , stopped with <code>log stop</code> , cleared with <code>log erase</code>)	Capture and review received-packet activity
<code>reboot</code>	(restarts device)	Recover from hung state

Note: `contacts` and `list` are companion/client-side concepts, not repeater serial commands - on a headless repeater, use `neighbors` instead. The `log` command is a packet/rx capture you start and stop, not an always-on event log.

Interpreting Stats Output

The `stats-packets` command is a useful diagnostic tool. The firmware exposes Received and Sent counters. A healthy repeater shows:

- **Sent count tracking received traffic** - the repeater is relaying packets it is meant to forward. (The documented counters are Received and Sent; there is no separate "forwarded" or "dropped" counter, so judge activity from the Sent counter rising alongside Received rather than from a "forward rate" metric.)
- **Drops in MeshCore** - MeshCore drops a flood packet when it exceeds the `flood.max` hop ceiling (default 64), and its loop detection (`loop.detect`) drops a packet whose path shows this repeater's own ID/hash repeated. This is not a Meshtastic-style per-packet hop counter decrementing to zero. In MeshCore's path-based routing, a repeater also intentionally does *not* retransmit packets whose embedded path does not include it - these appear as non-forwarded traffic but are correct behavior, not a loop. Distinguish this selective non-forwarding from a genuine duplicate-flood loop before acting.
- **Increasing received count over time** - Confirms the repeater is hearing traffic from the network

Common Issues and Diagnostics

Symptom	Check	Fix
---------	-------	-----

Received count stays at zero	Check antenna connection, verify radio settings match network	Reconnect antenna; verify radio parameters with <code>get radio</code> and <code>get freq</code> (frequency, bandwidth, SF, coding rate) and confirm they match the USA/Canada preset values shown in the app
Sent count zero despite receives	Verify device is running repeater firmware variant and that forwarding is enabled	Reflash with repeater firmware; confirm <code>set repeat on</code>
Battery voltage declining	Check solar panel output, charge controller LVD setting	Clean panel, verify charge controller settings
Rebooting frequently	Check for low battery voltage causing brownout	Size battery correctly; check charge controller
Not appearing in client node list	Repeater may not be sending flood adverts; check the flood advert interval with <code>get flood.advert.interval</code>	Send a flood advertisement with <code>advert</code> and confirm a flood advert interval is set, e.g. <code>set flood.advert.interval 12</code> (hours). Zero-hop adverts (<code>advert.zerohop / set advert.interval</code>) are local only. There is no <code>advert_hops</code> parameter.

Revision #3

Created 2026-05-03 05:46:19 UTC by Mesh America Admin

Updated 2026-06-09 00:56:30 UTC by Mesh America Admin