

Solar System Sizing Guide

Goal

Size your battery to survive N cloudy days, and size your panel to fully recharge that battery against your worst-month (winter) sun — with real positive margin, never sized "exactly" to the minimum.

Step 1 - Measure Your Device's Actual Current Draw

Use a coulomb-counting USB power meter (or a meter that logs mAh/Wh) over a multi-hour test. A plain multimeter in series reads only *instantaneous* current and will under-estimate average draw — radios spend most of their time receiving (low current) and only briefly transmitting (high current), so you must integrate consumption over time (mAh/Wh), not read a single instantaneous value. Do not rely solely on datasheet figures — real-world draw depends on firmware, radio duty cycle, and accessories.

Representative average current values (measure your own; these are examples, not specs):

Device	Avg Current
ESP32 repeater (Heltec V3, no display, BT/Wi-Fi off)	~40 - 80 mA (light traffic toward the low end; default/higher-traffic configs higher)
nRF52840 repeater (RAK4631 / T114), RX-mode average	~10 - 15 mA (aggressive power-saving firmware can reach ~7.5 mA)
Pi Zero 2W gateway (idle/light load)	~100 - 150 mA at 5V (an active gateway under Wi-Fi traffic can exceed 150 mA)
Pi 3B+ gateway (idle)	~300 - 400 mA at 5V (a busy gateway draws 500 mA+, peaking near 950 mA under load)

Step 2 - Calculate Daily Energy

Work in watt-hours so device voltage is explicit. Daily energy: $\text{Wh/day} = \text{average current (mA)} \times 24 \text{ h} \times \text{system voltage (V)} \div 1000$. To get amp-hours at a given bus voltage, divide Wh/day by that voltage. (mA × h alone gives Ah *at the device's own voltage* — you must multiply by voltage to get Wh, and account for voltage when sizing a battery at a different bus voltage.)

Example: a 60 mA ESP32 repeater on a 3.7 V single-cell bus = $60 \times 24 \times 3.7 \div 1000 \approx 5.3 \text{ Wh/day}$, which is $\sim 1.4 \text{ Ah/day}$ at 3.7 V. If you instead power it from a 12 V LiFePO4 pack through a buck converter, the same 5.3 Wh/day is only $\sim 0.44 \text{ Ah/day}$ at 12 V, *plus* converter losses.

Step 3 - Size the Battery for Cloudy Days (with margin)

Multiply daily energy by the number of consecutive no-sun days you must survive. For general installs plan 3 - 5 days of reserve; for **emergency-comms nodes plan 5 - 7+ days**, because panels contribute nothing during a multi-day overcast or snow-covered stretch.

Example (5.3 Wh/day ESP32, 5-day reserve): $5.3 \text{ Wh/day} \times 5 \text{ days} = 26.5 \text{ Wh}$ of usable reserve needed.

For LiFePO4, plan to 80% depth of discharge for longevity — usable capacity = rated × **0.80**. Sizing the pack *exactly* to the minimum leaves zero margin and ignores self-discharge, BMS/converter losses, cold-temperature capacity loss, and aging. Add real margin — roughly 1.3 - 2× the bare minimum. For the 5-day ESP32 case above ($\sim 26.5 \text{ Wh}$ usable need \approx a $\sim 33 \text{ Wh}$ pack at 80% DoD), step up to a $\sim 50 - 65 \text{ Wh}$ pack (e.g. an 8 - 10 Ah pack on a 6.4 V or 12.8 V bus) rather than sizing it razor-thin.

Step 4 - Size the Solar Panel

A solar panel produces roughly its rated wattage for a number of "peak sun hours" (PSH) per day. **Do not assume a flat "4 PSH year-round."** Use your location's *winter* PSH from NREL PVWatts: northern-US winter is only $\sim 1 - 2.5 \text{ PSH}$ (Seattle/Portland ~ 1.5 , Chicago ~ 2.5 , Anchorage ~ 0.5). Size the panel against the worst-month PSH and size the battery for cloudy-day reserve.

Energy harvested: $\text{Wh/day} = \text{panel watts} \times \text{PSH} \times \text{derate}$, where the overall **derate factor is 0.75** (it lumps controller, wiring, temperature, and soiling losses). To convert to amp-hours at the battery, divide by the battery charging voltage. For a PWM controller, current into the battery is roughly the panel's I_{mp} (PWM clips panel V_{mp} to battery voltage); for MPPT, use the power form (panel W × PSH × derate) ÷ battery charging voltage, since MPPT converts power rather than clipping voltage.

Example: a 5 W panel at a winter minimum of 2 PSH →

$$5 \text{ W} \times 2 \text{ h} \times 0.75 = 7.5 \text{ Wh/day harvested}$$

That still covers a ~5.3 Wh/day ESP32 repeater, but with thin margin and no allowance for consecutive overcast days. At a northern latitude, step up to a 10 W panel for reliable winter recharge.

Step 5 - Account for Worst-Case Latitude and Season

Latitude $>45^\circ$ (northern US, Canada) in winter may have only ~1 - 2.5 peak sun hours — and that figure describes *clear* winter days. During storms, prolonged overcast, and snow cover, real harvest can fall to near zero for days at a time. Size the panel for the winter minimum **and** size the battery for 5 - 7+ consecutive no-sun days at high latitude. Check and clear snow from panels in winter.

Quick Reference Table

Device currents below are representative receive-mode/idle figures (measure your own). The mA values are at each device's own input voltage; the Ah/day column is computed at that voltage. When powering from a higher-voltage battery (e.g. 12 V LiFePO4) through a converter, convert via watt-hours and add converter loss. Battery and panel columns already include margin for cloudy-day reserve and winter PSH.

Device	Avg mA	Ah/day (at device V)	Recommended Battery	Recommended Panel
nRF52840 repeater	~12 mA	0.29 Ah @ device V	3 - 5 Ah LiFePO4	3 W minimum
ESP32 repeater	~60 mA	1.4 Ah @ device V	8 - 10 Ah LiFePO4	5 - 10 W
Pi Zero gateway (idle)	~125 mA @ 5V	3.0 Ah @ 5V (≈ 1.4 Ah/day at 12V + loss)	15 - 20 Ah LiFePO4	20 W
Pi 3B+ gateway (idle)	~350 mA @ 5V	8.4 Ah @ 5V (≈ 3.8 Ah/day at 12V + loss; active load draws more)	40 Ah LiFePO4	50 W

Revision #3

Created 2026-05-03 04:12:16 UTC by Mesh America Admin

Updated 2026-06-08 22:54:36 UTC by Mesh America Admin